


BEZIER SETUP FOR CORELDRAW

When using CorelDraw you have the option to turn on Beziers for vector output. This has a number of benefits and will create curves, arcs and circles that are smoother and crisper.

The information below will explain how to turn on Beziers in Corel.



1. On the Corel menu bar, click on **“Tools”**. Then select **“Options”** from the drop down menu.
2. Notice the Options dialog is divided into two sections. Along the left section, click the arrow next to **“Global”** to expand its contents.
3. Click on the arrow next to **“Printing”** to expand its contents and click **“Driver Compatibility”**.
4. At the top of the right section, use the dropdown to select the **Xenotech_Driver**
5. Check the box next to **“Send beziers and paths to driver”** and click OK.

